



## Camaro 16-19 SS Wicker Bill Install

*Note: Perform the following steps with the Wickers Bills plastic coating still on the wicker bill.*



- 1.) Align the wicker bill center on the spoiler and mark your center hole
- 2.) Drill a 11/64 hole and bolt the sub wicker on that marking
- 3.) With the sub wicker bolted to the spoiler, align and mark the remaining holes
- 4.) Remove the wicker and drill out the remaining marked holes
- 5.) Remove plastic protective covering and now bolt the wicker bill to your spoiler.

If you have any questions or need additional information please email: [info@zl1addons.com](mailto:info@zl1addons.com) or give us a call M-F 7AM-2PM PT. 858 527 8727